



FLOW CONDITIONING CORP.

WWW.FLOW-C.COM

12 KIMLER DRIVE MARYLAND HEIGHTS, MO 63043-3797 (314) 878-7898 FAX (314) 878-6029

May 31st, 2023

FLOW CONDITIONING TRUMPET VALVE, HYDRONIC INDICATOR, AND FLANGE ADAPTER SELECTION SHEET

HYDRONIC INDICATOR SYSTEMS

TWO PORT SYSTEM

TVI-260	5#
TVI-2100	5#
TVI-2150	5#
TVI-2200	5#

THREE PORT SYSTEM

TVI-360	6#
TVI-3100	6#
TVI-3150	6#
TVI-3200	6#

FOUR PORT SYSTEM

TVI-460	6#
TVI-4100	6#
TVI-4150	6#
TVI-4200	6#

NOTE: Hydronic Indicator System Includes: 60#, 100#, 150# or 200# Indicator and Trumpet Valve with Bracket and Test Port Connector

HYDRONIC INDICATOR ONLY

HI-60	HI-100	HI-150	HI-200	3#
-------	--------	--------	--------	----

TRUMPET VALVE ONLY

TV-2	Two Port Trumpet Valve	2#
TV-3	Three Port Trumpet Valve	3#
TV-4	Four Port Trumpet Valve	3#

NOTE: Mounting Bracket and Test Port Connector included with Valve. If Tubing Connectors are required, use the following additions.
(Connectors are 1/4" MPT x 1/4" Compression)

2PC	Two Port Connectors	(4 Connectors)
3PC	Three Port Connectors	(6 Connectors)
4PC	Four Port Connectors	(8 Connectors)

FLANGE ADAPTERS

<u>MODEL</u>		<u>A 125#FLG.</u>	<u>B 125#FLG.</u>	
FCC3025	Flange Adapter	3	2-1/2	19#
FCC4025	Flange Adapter	4	2-1/2	26#
FCC4030	Flange Adapter	4	3	28#
FCC5030	Flange Adapter	5	3	35#
FCC5040	Flange Adapter	5	4	39#
FCC6040	Flange Adapter	6	4	47#
FCC6050	Flange Adapter	6	5	50#
FCC8050	Flange Adapter	8	5	71#
FCC8060	Flange Adapter	8	6	77#
FCC1080	Flange Adapter	10	8	76#
FCC1210	Flange Adapter	12	10	105#
FCC1412	Flange Adapter	14	12	136#

SUCTION DIFFUSER PARTS

OCA	Orifice Cylinder Assembly - A-Body (less start-up strainer)	7#
OCB	Orifice Cylinder Assembly - B-Body (less start-up strainer)	9#
OCC	Orifice Cylinder Assembly - C-Body (less start-up strainer)	24#
ORA	O-Ring - A-Body	
ORB	O-Ring - B-Body	
ORC	O-Ring - C-Body	
SDF	Support Foot Assembly	1.4#